



POWERVENT INSTALLATION

INSTRUCTIONS

Step 1



(1) Make sure all components are in box

TOOLS REQUIRED

- Flat screwdriver
- #2 Phillips screwdriver
- *5-12 Volt power supply

OPTIONAL

- Cordless drill/driver
- #2 Phillips bit

*Power supply not included

Step 2



(2) Using a flat screwdriver, remove existing lower vent



POWERVENT INSTALLATION

INSTRUCTIONS

Step 3



(3) Install both leveling feet in bottom of fan box

Step 4



(4) Install rubber grommet, make sure the larger tapered flange goes into hole in blind



POWERVENT INSTALLATION

INSTRUCTIONS

Step 5



(5) Place fan box outlet tube through grommet hole inside blind

Step 6



(6) Level fan box by screwing feet in or out



POWERVENT INSTALLATION

INSTRUCTIONS

Step 7



(7) Slide exhaust snorkel over outlet tube until it seals on tapered grommet

Step 8



(8) Secure snorkel to outlet tube using two screws



POWERVENT INSTALLATION

INSTRUCTIONS

Step 9



(9) Place scent tray in fan box

Step 10



(10) Place cover on fan box



POWERVERT INSTALLATION

INSTRUCTIONS

Step 11



A



B

(11) Plug in 5-12 volt power supply (not included) using USB-C plug connection
